


DYNAMIC STABILITY CONTROL(DSC)SYSTEM

O-a



166

<p>O-01 DSC HU/CM(F)</p>	<p>O-02 ABS WHEEL-SPEED SENSOR LF(F)</p>	<p>O-03 ABS WHEEL-SPEED SENSOR RF(F)</p>
<p>O-04 ABS WHEEL-SPEED SENSOR LR(R)</p>	<p>O-05 ABS WHEEL-SPEED SENSOR RR(R)</p>	<p>O-06 DSC OFF SWITCH(I)</p>
<p>O-07 STEERING ANGLE SENSOR(I)</p>		

HARNESS SYMBOL:  (F)  (E)  (R)

